



CE


LED Linear Light ECO

Features and benefits

- ZOLU Lighting quality and reliability
- 30,000hrs lifespan
- Ambient temperature -40 to +40°C
- Work with AC120-277V directly
- IP65 rating, suitable for damp locations & dust proof
- Stainless steel surface mounting clamps
- Flicker-free driver

Applications

- Factories, cold storage and production areas
- Warehouses and storage rooms
- Shopping mall, stairways and parking lots



Technical specifications

Product code	Power	Light output	Size	Dimensions
ZL35W12LL50KECO	35W	4900lm	4ft	1200*34.5*36.5mm



CE **RoHS
COMPLIANT**



Main voltage	AC100-277V 47/63Hz
Efficiency	140lm/W
CRI	Ra>80
Power factor	>0.9
Housing	Aluminum 6063-T5 / PC Frosted optics
Ingress Protection	IP65
LED quantity	144 pcs 0.5W 2835
Beam spread	120°
CCT	5000K
Certificates	CE / RoHS
Warranty	3 Year

LED Linear Light ECO Installation

WARNING

1. Use a qualified electrician for installation of this lighting fixture.
2. Before installing the fixture disconnect power by shutting off the circuit breaker or by removing the fuse at the fuse box.
3. All electrical connections must be in accordance with local and National Electrical Code.
4. Switch ON only after complete installation and examination of the circuit.








CAUTION:

- The installation should be done by an individual familiar with the construction and operation of the luminaire.
- This luminaire must be directly wired on line. Any ballast or other power device previously used with the replaced luminaire must be removed.
- Between the luminaire and any possibly flammable material must be an appropriate safety space (at least 20cm).
- The luminaire must not be covered with heat insulating materials.
- Always provide proper ventilation around the luminaire and do not exceed the maximum ambient temperature.

Turn OFF power supply before starting any installation. Read instructions and check you have all the tools and accessories to complete the installation correctly.

Installation instructions

 Drill holes in the ceiling / wall 1	 Put in dowels 2	 Screw on the mounting clamps 3
 Install the light on the clamps 4	 Connect to the power supply according to rated voltage of lighting fixture 5	 AC 100-277V Turn on power supply. Installation complete 6

